



INSTALLATION

- Insert MSR end of device into case
- Push down on EMV end to fully snap device into case